

Cut slots into concrete at 1/8" W x 1/8" D. Slots should be close to drain to allow for clean finish when applying coating.